



Lenovo Yoga 710-11ISK Disassembly

Written By: Michael J Regan

INTRODUCTION

Crashed hard. Unsuccessfully tried to get it to boot after using it for about 6 months. It reboots, shows Lenovo splash screen, then white dots cycle in a circle over and over, lather, rinse, repeat. Tried all F keys, ctrl alt del, etc etc. Ended up calling India, oops, I mean warranty repair, to no help. Got an RMA, told to take it back to Best Buy. HOWEVER, I would lose all data. Yeah, I know, create a Win 10 Boot Flash... too much trouble. Going down on her now.

Back side or bottoms up, you'll need a pentalobe bit or screw driver. Let me see what size. BTW, no stickers that say warranty voided if open, nor any seals to break. It takes a pentalobe 5, i.e. P5. Taking a break, I'll go down on her later. Oh, taking her apart because I want my files from the SSD?). June 11, 2016

Removed all PS screws. Keep them in a magnetized bowl, as they are extremely small.

You'll also need a plastic spade, similar to the ones used to open or repair cell phones. Be very careful using the spade around the touchpad as the metal on the edge is very flimsy.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-23 09:36:34 PM.